

# LUXURY LINER™ MASS LOADED VINYL ROLL

## WALL INSTALLATION INSTRUCTIONS

### RECEIVING AND HANDLING

Luxury Liner™ Mass Loaded Vinyl should be stored indoors until ready to use. These rolls are very heavy, so be sure to have assistance when moving or installing the MLV.

### INSTALLATION TOOLS

- Mechanical fasteners of choice: nails, staples, or screws (with washers)
- Sharp utility knife, or sharp shears (sharp!)
- 48" Drywall T-Square
- Level
- Acoustic caulk and foil tape for seams and edges

### HOW TO INSTALL

- 1 Measure the height of the wall from top to bottom and roll out the MLV so the length of the material matches the wall's height. Deduct 1/8", then mark it.
- 2 Cut the MLV at the marked line using a sharp utility knife and a T-square to ensure a straight cut. Make appropriate cuts for outlets, light switches, or other penetrations.
- 3 Fasten the MLV to the studs using staples, screws, or nails at the top of the wall and work your way across, ensuring to stay straight using your level. Fasteners should be placed every 8" along each stud and along the top and bottom.
- 4 Repeat steps to make more cuts. When installing the sheets side-by-side, butt the edges up against one another along a stud for an airtight installation.
- 5 Seal the seams and edges with acoustic caulk when they line up along a stud or with foil tape over an airgap.
- 6 Seal up the MLV behind a layer of drywall and use acoustic caulk around the perimeter and any other outlets or fixtures.



Do not cover any outlets, light switches, or other penetrations with the mass loaded vinyl and only hang on studs. If you cannot avoid the edges meeting over an airgap, overlap the MLV by 2" and seal with foil tape.